



Installation Instructions Suspender Adaptor Kit

1. Cut Holes
2. Cut Saddle tape.
3. Thread ribbon through panels.
4. Install cord lock.
5. Adjust height of Door Shield.

